



# Installation Instructions

## iBoard™ by APS Auto Parts Specialist Inc.

Estimated Time: 1 to 2 hours

Submit before and after photos to [iboardauto.com](http://iboardauto.com) for a chance to win prizes!



Disclaimer: Instructions intended for persons aged 18+ please do not attempt without adult supervision. Instructions are not intended to replace professional installation. Damage from improper installation, misuse or modification to the product voids the manufacturer's warranty.




# iBoard™

### Attention

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.





PARTS LIST:



Item	QTY	Description	Item	QTY	Description
#01	2	STEP BOARD, Driver/+Passenger	#06	12	M8 Lock Washers
#02	3	Passenger Front Mounting Bracket (PFM/PCM/DRM)	#07	12	M8 Clip Nut
#03	3	Driver Front Mounting Bracket (DFM/DCM/PRM)	#08	12	M6 Square Head Bolts
#04	12	M8X1.25-30 Hex Bolts	#09	12	M6 Flat Washers
#05	12	M8 Flat Washers	#10	12	M6 Nylon Lock Nuts



PROCEDURE

Step	Procedure	Picture
1	Remove contents from box, verify if all parts listed are present and undamaged. Carefully read and understand all instructions before attempting installation.	
2	Start the installation under the passenger side of the vehicle. Locate the (4) factory running board mounting locations along the bottom and inner side of the body, <b>(Figure 1)</b> . Mounting Brackets will bolt to the 1st, 2nd and 4th mounting locations. <b>NOTE:</b> It may help to hold a Bracket up in place to help determine the mounting holes to use along the bottom and inner side of the body.	<p>(Figure 1) Passenger side mounting locations along bottom and back of body panel illustrated</p>

Step	Procedure	Picture
3	Remove rubber plugs as necessary from the (2) factory mounting holes, <b>(Figure 2)</b> .	 <p><b>(Figure 2) Remove plugs from mounting locations as necessary</b></p>
4	<p>Select (1) M8 Clip Nut. Slide the Clip Nut into the large hole and over the smaller hole next to it. Line up threaded nut on the Clip Nut with smaller hole in body panel, <b>(Figure 3)</b>.</p> <p><b>Repeat to install a 2nd Clip Nut in the remaining front mounting hole.</b></p>	 <p><b>(Figure 3) Slide M8 Clip Nut into large hole and over small hole</b></p>
5	Select (1) Mounting Bracket, Attach the Bracket to the (2) M8 Clip Nuts with (2) M8X1.25-30 Hex Bolts, (2) M8 Lock Washers and (2) M8 Flat Washers, <b>(Figure 4)</b> . Snug but do not fully tighten the hardware.	 <p><b>Figure 4</b></p> <p>Install mounting bracket with supplied M8 Hardware.</p>
6	Repeat Steps 3—5 for Center and rear Mounting Bracket installation.	
7	Select (1) Running Board and (6) M6X20 Square Head Bolts. Locate the opening in the end of each channel in the bottom of the Running Board. Slide (3) Square Head Bolts into each channel, <b>(Figure 5)</b> .	 <p><b>(6) M6X20 Square Head Bolts</b></p> <p><b>Figure 5</b></p>
8	With assistance, carefully position the Running Board onto the (3) Mounting Brackets. Lift the Running Board up and slide the Square Head Bolts along the channels to line up with the Brackets. <b>IMPORTANT:</b> Do not slide the Running Board on the Brackets, (front to back or rotate), or the finish on the Running Board may be damaged.	

Step	Procedure	Picture
9	Attach the Running Board to the Brackets with (6) M6 Flat Washers, (6) M6 Nylon Lock Nuts ( <b>Figure 6</b> ). Do not tighten hardware at this time.	
10	Properly level and adjust the Running Board and fully tighten all hardware. <b>NOTE: Torque all M6 nylon lock nuts to 7 lb-ft.</b>	
11	Repeat <b>Steps 2—10</b> to install the driver/left Running Board.	
12	<b>INSTALLATION IS COMPLETE!</b>	
13	Do periodic inspections to the installation to make sure that all hardware is secure and tight.	

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For Polished Finishes:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

**For black finishes:** Mild soap may be used to clean the Running Board.